




2009-2015 Toyota Prius Engine Air Filter Replacement

Are you noticing a decrease in fuel economy? The simple cheapest fix is to replace the engine air filter. Follow this free video guide to do it yourself!

Written By: eCuration



This document was generated on 2019-09-30 08:36:15 PM (MST).

INTRODUCTION

The engine air filter should be replaced once every two years.

Follow this video tutorial by YouTuber [NutzAboutBolts](#) to complete the replacement yourself.

TOOLS:

- [Pair of Hands](#) (1)

PARTS:

- [Engine Air Filter](#) (1)

To reassemble your device, follow these instructions in reverse order.