



2009-2015 Toyota Prius Transmission Fluid Replacement

A video tutorial on how to change the automatic transmission on a 2009-2015 Toyota Prius by drain and refill method.

Written By: eCuration



This document was generated on 2019-09-23 05:02:05 AM (MST).

INTRODUCTION

The transmission fluid on a Toyota Prius should be drained and refilled every 60,000 miles.

Follow this video tutorial by YouTuber [NutzAboutBolts](#) to complete the job yourself.

TOOLS:

- Hydraulic Floor Jack (1)
- Jack Stands (1)
- Wheel Chocks (1)
- 1/2" Drive Breaker Bar (1)
- 3/8" Drive Ratchet (1)
- 3/8-Inch Drive Extension Bar (1)
- 10mm Socket (1)
- 10mm Allen Wrench (1)
- Fluid Hand Pump (1)
- Oil Drain Pan (1)
- Paper Towels (1)
- WD-40 (1)
- Flathead Screwdriver (1)

PARTS:

- Automatic Transmission Fluid 1 qt. (5)
- Oil Drain Plug Gasket (1)

To reassemble your device, follow these instructions in reverse order.