



2012 Ford Fusion Headlight Replacement

Learn how to replace the headlight bulb on a 2012 Ford Fusion

Written By: Angelica



INTRODUCTION

This guide will show you how to change a worn out headlight bulb for a 2012 Ford Fusion as quickly as possible

TOOLS:


- [Socket Set \(1\)](#)

Step 1 — Headlight



- Locate the hood latch and pull it to open

Step 2



- The front hood will open and be caught by a safety latch. Run fingers under the hood and push the latch to the left to open the hood completely

Step 3



- Hold up the hood with the hood support rod

Step 4





- Remove negative terminal from the battery using a 10mm socket. Remove the bolt that is holding the negative terminal and pull terminal off the battery.

Step 5





- Locate the headlight bulb in the front of the car under the hood and twist off the cap covering the headlight bulb

Step 6



- twist the housing to the light bulb and pull it out

Step 7



- unclip the light bulb from the housing latch and replace light bulb

To reassemble your headlight, follow these instructions in reverse order.