



2012 Ford Fusion Windshield Wiper Replacement

Learn how to replace the windshield wiper on a 2012 Ford Fusion

Written By: Matthew Williamson



INTRODUCTION

This guide will show you how to change a damaged or worn out windshield wiper for a 2012 Ford Fusion as quickly as possible.

Step 1 — Windshield Wiper




- Locate wiper blade arm and pull away from windshield until it is locked in place pointing directly away from the windshield.

Step 2



- Rotate the wiper blade perpendicular to the wiper blade arm.
- Pull the rigid part of the wiper blade down the arm (directly toward the windshield).

Step 3



- Once the clip on the windshield wiper clears the hook on the arm, your windshield wiper is completely removed.

To replace your wiper, follow these instructions in reverse order.