



# ACER Aspire 7750G-6645 Hard Drive Replacement

This following guide is showing the step by step, how to replace the ACER Aspire 7750G 6645 hard drive.

Written By: Thong



## INTRODUCTION

If your laptop is currently experiencing full memory then this guide below will show you step by step how to replace the ACER Aspire 7750G 6645 Hard Drive. Once the new Hard Drive is installed the memory of the laptop will be empty.

### TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [Spudger](#) (1)

### PARTS:

- [ACER Aspire 7750G-6645 Back Cover](#) (1)
- [ACER Aspire 7750G-640 Hard Drive](#) (1)

## Step 1 — Back Cover



- Remove three 60mm Phillips #00 screws that are holding the bottom cover in place.

## Step 2



- Lift up the back cover of the device, you may need to use a spudger to assist.

## Step 3 — Hard Drive



- Remove two 4mm Phillips #00 screws that are holding the hard drive in place.

## Step 4



- Push the hard drive to the right and push it upward to remove. You may need a spudger or plastic opening tool to assist you with this step.

To reassemble your device, follow these instructions in reverse order.