




ACER Aspire 7750G-6645 Keyboard Replacement

This is a guide for an ACER Aspire 7750G-6645. A guide to replace the keyboard if there are many keys missing, or if it stops working entirely.

Written By: Zachary Simao



This document was generated on 2020-01-30 05:15:33 PM (MST).

INTRODUCTION

This is a guide for an ACER Aspire 7750G-6645. This guide shows the replacement of the keyboard. If there are many missing keys or if the keyboard isn't working properly, this guide may be helpful.


TOOLS:

- Spudger (1)
- Flathead 3/32" or 2.5 mm Screwdriver (1)

PARTS:



- ACER Aspire 7750G-6645 Keyboard (1)

Step 1 — Keyboard



- Turn off the laptop, and open the lid.
- Separate the first two layers by prying them apart, using a spudger.

Step 2



- Lift the keyboard, so that its ribbon is visible.
- Remove the ribbon from the board by using a small metal spudger or flathead screwdriver. (if needed)

To reassemble your device, follow these instructions in reverse order.