



ARC-914SBD Lid Replacement

Show the removal of the lid allowing for the rest of the components to be reached.

Written By: Brandon Nieves



INTRODUCTION

This is the first step taken in order to fix many of the parts in this device. Be careful to not strip any of the screws.

TOOLS:

- **Phillips #2 Screwdriver (1)**

Step 1 — Lid



- Begin by removing the condensation catcher to expose the screw. Pinch the condensation catcher from both sides and pull.

Step 2



- Remove the screw that was behind the condensation catcher using a Phillips head screwdriver, size PH2.

Step 3



- Remove the piece that was held by the screw by pulling out from the top, then pulling up. This will expose the hinges for the lid.

Step 4



- To remove the hinges, rotate the bottom of the rod upwards, then push inwards to pull them out. Repeat the process for both sides. This will allow the lid to be removed.

To reassemble your device, follow these instructions in reverse order.