




ASUS Q324UA-BHI7T17 Keyboard Keys Replacement

A step by step guide on how to quickly and easily replace certain keyboard keys on the ASUS Q324UA-BHI7T17.

Written By: Scott Santiago



This document was generated on 2019-10-14 06:39:06 PM (MST).

INTRODUCTION

Over time a laptop keys will be pushed a good amount, therefore it is no surprise that certain keys begin to stop working. Keyboard keys are easy to find on the market, and once a replacement key is bought follow these steps to replace that certain key.



TOOLS:

- iFixit Opening Tools (1)
- Flathead 3/32" or 2.5 mm Screwdriver (1)

PARTS:


- Asus K55 Replacement Keyboard Keys (1)

Step 1 — Keyboard Keys





- First, insert the opening tool, between the key cap and the hinge and push up gently.
- *(i)* The key should pop out easily.

Step 2



- Place the flat head screwdriver between the two parts of the plastic hinge, and turn it a little so the first part pops out.
- You can start on either side, either the right or the left it does not matter, just make sure to do both sides.

Step 3



- Next remove the last plastic piece from the keyboard, and properly dispose of all three parts.

This document was generated on 2019-10-14 06:39:06 PM (MST).

To reassemble your device, follow these instructions in reverse order.