




ASUS VivoBook S400C Battery Replacement

How to replace the battery for the ASUS VivoBook S400C.

Written By: Ashley Panduro



INTRODUCTION

If your ASUS VivoBook S400C has an extremely short battery life or does not hold a charge, use this guide to replace the battery.

Over time, a battery may degrade in quality and fail to hold a long charge or take a charge at all. Before using this guide, check that [no other factors are preventing a charge](#).

Before beginning, make sure your laptop is powered off and disconnected from any external power source. Take extra care if your [battery is swollen](#).

TOOLS:

- [Phillips #0 Screwdriver](#) (1)
- [Spudger](#) (1)

Step 1 — Battery




- Flip the device over and remove the ten 5.7 mm screws with a Phillips #0 screwdriver.

Step 2



- Use a spudger or your fingers to go around and lift the edges and release the back panel.

Step 3




- Using a spudger, lift up the ribbon cable connecting the battery to the motherboard.

Step 4



- With a Phillips #0 screwdriver, remove the four 5.7 mm screws holding the battery to the laptop.

Step 5



- Carefully lift the battery up and out of the device.

To reassemble your device, follow these instructions in reverse order.