




# ASUS X42J Keyboard Replacement

This guide will articulate the process for replacing the keyboard.


Written By: Robert Martinez



 **TOOLS:**

- Metal Spudger (1)
- Nylon Tipped Tweezers (1)

## Step 1 — Keyboard



ⓘ Make sure your device is unplugged and turned off before proceeding.

- Using a [Spudger](#), gently pry up the keyboard.

## Step 2



- Rotate the keyboard to face downward.
- Pull out the blue wiring connection. Use [tweezers](#) to make it easier to remove.

To reassemble your device, follow these instructions in reverse order.