



# ASUS X550LB-DS71 Display Panel Replacement

This guide will show the steps needed to replace the display panel in ASUS X550LB-DS71.

Written By: Nathan Dyer




## INTRODUCTION

The display monitor is an output device which presents data on the screen. It is what allows the user to see what inputs they are putting into the device.

### TOOLS:

- [Phillips #0 Screwdriver \(1\)](#)
- [iFixit Opening Tools \(1\)](#)

## Step 1 — Display Panel



- Flip open the laptop with the screen facing towards you.
- Using the plastic opening tool, remove the square tape from the marked locations.
- Use the Phillips #0 Screwdriver to remove the two 2mm screws from those locations.

## Step 2



- Using the plastic opening tool, open the front cover of the laptop.

*(i)* It is recommended that you start from a corner and run the tool along the edge of the cover.


**⚠** Be careful not to bend or crack the cover.

## Step 3



- Peel off the tape located on the left and right side of the display monitor.
- Use the Phillips #0 screwdriver to remove the screws at the marked locations in each corner of the display.

## Step 4



- Place the display monitor face down to expose the ribbon connector.
- Remove the ribbon connector to separate the display monitor from the rest of the device.

To reassemble your device, follow these instructions in reverse order.