



ASUS ZenBook UX302LA-BHI5T08 Back Cover Replacement

How to replace the back cover of an ASUS ZenBook UX302LA-BHI5T08.

Written By: Kristen Gismondi



 **TOOLS:**


- [Spudger \(1\)](#)
- [Phillips #00 Screwdriver \(1\)](#)

Step 1 — Back Cover



- Flip the laptop over so the model stickers face the ceiling.

Step 2



- Remove eleven 7mm Phillips #00 screws that secure the back cover.
- Two screws are under the rubber pad.

Step 3



- Using a spudger, carefully remove the back cover.

To reassemble your device, follow these instructions in reverse order.