



Acer Aspire 3003WLCi Battery Replacement

This guide was created to demonstrate the battery replacement of an Acer Aspire 3003WLCi.

Written By: Tristin Viale



INTRODUCTION

In this guide, you will be instructed on how to replace the battery in your laptop. The battery allows for your laptop's mobility feature, as it keeps the laptop powered on while disconnected from an outlet.


This replacement is not difficult and will take you no more than a minute to complete. It requires no tools, and can be completed in 3 steps.

Step 1 — Battery



- Turn the Acer Aspire 3003WLCi so that the bottom of the laptop is facing up. Orient it so that the battery is on your left.

Step 2



- There will be two switches on the back of the laptop: one at the top of the battery, and one at the bottom.
- Shift the bottom switch into an upward position in order to unlock the battery.
- To unlock the upper switch, forcefully push the switch up and hold it in this position.

Step 3



- While holding the upper switch in the upward position, remove the battery by pulling it out to the left.
- You may need to be a bit forceful when pulling the battery to the left if it hasn't been removed before.

⚠ You have to maintain pulling the upper switch upwards, or the battery will not come out.

To reassemble your device, follow these instructions in reverse order.