



Acer Aspire 4743-6481 Battery Replacement

This guide provides detailed instructions on how to remove and replace the battery of the Acer Aspire 4743-6481.

Written By: Filippo Santoro



INTRODUCTION

If your device's battery depletes quickly or doesn't last at all while unplugged, you should use this guide to replace it with a new one.

TOOLS:

- [Tweezers \(1\)](#)

Step 1 — Battery

- Turn over the laptop to view the underside.



Step 2

- Use tweezers (or a similar tool) to slide the orange push pin. To release the battery, push it to the left.



Step 3

- You can lift the battery up and out now.



To reassemble your device, follow these instructions in reverse order.