




Acer Aspire 5349-2592 Screen Replacement

This replacement guide will give simple instructions for the user to replace the LCD screen of an Acer Aspire 5349-2592

Written By: Abderahmane Naidjate



 **TOOLS:**


- Phillips #0 Screwdriver (1)

Step 1 — Screen




- Open the laptop and turn it so that it is facing you, the user.

Step 2



- Pry off the Acer 5349-2592 Plastic LCD bezel.

Step 3



- Using a Phillips screwdriver, unscrew the 1/4" screws that hold the screen in place.
- Begin to pry off the screen from the device. You may use a bezel provided by the iFixit tool kit, if force necessary.
- Handle the Acer 5349-2592 LCD hinges with care as they are delicate.

To reassemble your device, follow these instructions in reverse order.