



# Acer Aspire 5534-1096 Keyboard Replacement

How to replace keyboard for the Acer Aspire 5534-1096.

Written By: Brandon Hernandez



## INTRODUCTION

This guide will show you how to replace the keyboard in an Acer Aspire 5534-1096. A keyboard is an interface used to give commands to a computer. The effectiveness of a keyboard decreases over time. The keys are subjected to multiple keystrokes which weaken the mechanical and electrical connections underneath the keys.

## TOOLS:

- [iFixit Opening Picks set of 6 \(1\)](#)
- [Spudger \(1\)](#)

## Step 1 — Keyboard




- Insert an opening pick between the top left corner of the keyboard and the laptop body.

## Step 2





- Slide the pick towards the other end of the keyboard to pop it out.

## Step 3



- Use the spudger to open the two latches holding the ribbon cable in place.

## Step 4



- Remove the ribbon cable by sliding it back.

## Step 5



- Remove the keyboard from the laptop.

To reassemble your device, follow these instructions in reverse order.