



# Acer Aspire E1-531-2438 Battery Replacement

This guide will show you how to remove and replace the battery on an Acer Aspire E1-531-2438.

Written By: Jakob Rinkus



## INTRODUCTION

Device not charging or not lasting a long time on a charge? This guide will show you how to remove and replace the battery on an Acer Aspire E1-531-2438.

### TOOLS:

- [Spudger \(1\)](#)

## Step 1 — Battery



⚠ Unplug and power down the device before removing the battery.

- Turn the device over so the back side is facing up.
- Using a spudger, slide the orange latch to the right. This will release the battery, which should pop up from the device.
- Use two hands tilt the side of the battery closest to the orange latch upward as shown in the images.

## Step 2



- Tilt the side of the battery closest to the orange latch upward.
- Lift the battery up and out of the device.

To reassemble your device, follow these instructions in reverse order.