



# Acer Aspire ES1-111M-C7DE Back Cover Replacement

This guide will show you how to remove the back cover from the Acer Aspire ES1-111M-C7DE.

Written By: Mason Devinney



## INTRODUCTION

This is a basic first step to working on any of the components under the cover. Be sure to have a space to store the screws while working on the device so that you do not lose any of them.

### TOOLS:

- JIS #0 Screwdriver (1)
- iFixit Opening Tools (1)

## Step 1 — Back Cover



- Unscrew the 13 6.2mm screws located on the bottom of the laptop using the JIS #0 screwdriver.

## Step 2



- Using a plastic opening tool, gently pry the lower case off. Place aside.

To reassemble your device, follow these instructions in reverse order.