



Acer Aspire One 722 Battery Replacement

A guide on how to replace the battery on the Acer Aspire One 722.

Written By: Christian Barboza



Step 1 — Battery



- Shut the netbook off (Power down netbook at top left corner).

Step 2



- Close the netbook and flip it over so that the back is facing up.

Step 3



- Slide the button below the battery to the right while simultaneously pulling the battery out.

Step 4



- Remove the old battery and get the replacement battery.

Step 5



- Check the thin grooves on the side of the battery entry and line the replacement battery up to that.

To reassemble your device, follow these instructions in reverse order.