




Acer Aspire One Cloudbook 14 AO1-431-C8G8

USB Port Replacement

This guide will show you the steps necessary to remove the USB port on one side of the Acer Aspire One Cloudbook 14 AO1-431-C8G8.

Written By: Joseph




INTRODUCTION

The USB port allows you to connect other devices to the laptop. This guide will show you how to remove and replace the USB port.

TOOLS:


- [Phillips #1 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)

Step 1 — Back Panel




- Remove the ten 7mm Phillips #0 screws from the bottom.

Step 2



- Insert a plastic opening tool under the bottom cover and slid it around the perimeter until all of the clips release.

Step 3 — USB Port



- Use a spudger to flip up the retaining flap on the ribbon cable [ZIF](#) socket.
- Remove the ribbon cable from the socket.

Step 4



- Remove the 5mm Phillips #0 screw from the USB port.
- Remove the USB port from the device.

To reassemble your device, follow these instructions in reverse order.