



Acer Aspire One D250-1151 Battery Replacement

This guide shows how to safely remove the battery from the laptop.

Written By: Evan Edmunds



INTRODUCTION

This guide will help the user locate and safely remove the battery.

Step 1 — Battery



 Make sure the computer is unplugged, and turned off completely

- Place the computer on a flat surface with the bottom facing you.

Step 2



- Place a finger on the small tab on the left with the lock and unlock symbols.
- Slide this tab to the unlock position.

 If done correctly, you should see an orange marker.

Step 3



- Place a finger on the tab in the upper right corner.
- Slide this tab to the right and hold it in that position.

Step 4



- Place your finger on the three lines in the middle of the battery while holding the tab on the right.

Step 5



- Push forward on the battery lines while holding the tab on the right.

To reassemble your device, follow these instructions in reverse order.