



Acer Aspire TimelineX 4820T-6645 Battery Replacement

How to replace a battery on a Acer Aspire TimelineX 4820T-6645

Written By: Michael Kilmartin



INTRODUCTION

If you need to replace the battery on a Acer Aspire TimelineX 4820T-6645 this guide will show you how to do so. You will not need tools to complete this replacement, and it is a fairly simple process.

Step 1 — Battery



- Power down the laptop.
- Turn the laptop over so the bottom is facing up and the battery is facing towards you.

Step 2



- The tab on the right is a locking tab. Slide this tab to the right to unlock it (the red should now be showing).
- Slide the left tab to the left and hold it there.

Step 3



- While holding the left tab to the left the battery should easily pull out of the laptop.

To reassemble your device, follow these instructions in reverse order.