




# Acer Aspire V5-131-2629 Cover Replacement

This guide will show how to replace the cover on the back of the Acer Aspire V5-131-2629.

Written By: Aaron Almeida



## INTRODUCTION

Useful guide to learn how to remove the cover on the Acer Aspire V5-131-2629

### TOOLS:

- [iFixit Opening Tools](#) (1)
- [Phillips #0 Screwdriver](#) (1)

## Step 1 — Battery



- Carefully turn your Acer Aspire V5-131-2629 upside down, so that the battery cell is visible and nearest to you.

## Step 2



- Identify the small, oval slide switch on the left hand side of the laptop, directly above the battery.

## Step 3




- Insert an opening tool into the hole on the right side of the oval switch. Use the opening tool to slide the switch to the right.

## Step 4



- With the switch engaged to the right, firmly pull the battery out and towards yourself, parallel to your work surface.

## Step 5 — Cover



- Remove the single Phillips #0 screw from the cover on the underside of the laptop.

## Step 6



- Remove the cover by sliding it outwards and remove it from the device.

To reassemble your device, follow these instructions in reverse order.