




# Acer Aspire V5-552PG-X469 Back Case Replacement

Remove the back case to access and replace the device's inner components.

Written By: Rebecca Aseo




## INTRODUCTION

This guide is a prerequisite to further replacement guides for inner components of the Acer Aspire V5-552PG-X469. Be sure to fully power off and unplug the device before starting.

## TOOLS:


- JIS #0 Screwdriver (1)

## Step 1 — Back Case




- Remove the storage tray on the left edge of the device.

## Step 2



- Use a Phillips #0 screwdriver to remove seventeen 7mm screws from the lower case.

## Step 3



- Lift up the back case to remove it.

To reassemble your device, follow these instructions in reverse order.