




Acer Aspire V5-571 Keyboard Replacement

Acer Aspire V5-571 Keyboard Replacement

Written By: ZFix



INTRODUCTION

How to replace not working keyboard (KB)

[Please SUBSCRIBE to my channel](#) ↴

[video: <http://youtu.be/mrKPiD7H0U>]

TOOLS:


- [Phillips #0 Screwdriver](#) (1)
- [Spudger](#) (1)

Step 1 — Keyboard



- Turn off the laptop and remove the battery.
- Remove two screws securing the Keyboard.
- The Keyboard is held by two locking clips, under the battery. Use the sharp tip of a plastic tool to release the keyboard.

Step 2



- Remove the Keyboard and disconnect the two flex cables:
 - Keyboard flex cable
 - Keyboard Light flex cable

 [Please SUBSCRIBE to my channel ↗](#)

To reassemble your device, follow these instructions in reverse order.

