



# Acer Chromebook 15 CB5-571-C09S Back Cover Replacement

Use this guide to replace the back cover of your Acer Chromebook 15 CB5-571-C09S.

Written By: Sakiynah Howard



## INTRODUCTION

This guide will walk you through replacing the back cover of your Acer Chromebook 15 CB5-571-C09S.

### TOOLS:

- [iFixit Opening Tools](#) (1)
- [Phillips #0 Screwdriver](#) (1)

## Step 1 — Back Cover




- Place the device on a flat surface faced down so that the fan vents are at the top of the device.

## Step 2



- Unscrew the eighteen 6 mm PH0 Phillips head screws from the back of the device.

## Step 3



- Use a plastic opening tool to pry open the back cover around the edges of the device.

! Be careful not to crack or break the back cover of the device.

i You will have to adjust the position of the device to pry it open along all the edges.

## Step 4



- Stand the device up with the hinges on top and carefully pull apart the back cover from the device.

To reassemble your device, follow these instructions in reverse order.