



Acer Chromebook C710-2833 Fan Replacement

The fan pulls air from the exterior of the laptop through the computer to help prevent the interior components from overheating.

Written By: Nicholas Latorre



INTRODUCTION

In this replacement guide, you will learn how to safely remove and install a cooling fan.

TOOLS:

- 64 Bit Driver Kit (1)
- Magnetic Project Mat (1)
- Anti-Static Wrist Strap (1)

PARTS:

- Acer Chromebook C710 CPU Cooling Fan (1)

Step 1 — Fan



- Flip your Chromebook over so the bottom is facing up.


Step 2



- Locate the 6 mm Phillips #00 screw that holds the back cover together. Use your driver with the PH00 bit attached to unscrew it.
- Once completely unscrewed, carefully lift the cover off.
- Place the cover and screw safely to the side for now.

This document was generated on 2019-10-20 07:33:23 AM (MST).


Step 3



- Now take your anti-static wrist strap and place it tightly on your wrist.
- Attach the alligator clamp of the wrist strap to something that will ground yourself to avoid possible electric zaps.


i The location chosen in the picture is recommended.

Step 4



- Locate the two 6 mm Phillips #00 screws on the fan port.
- Unscrew the two screws and place them aside for now.

Step 5



- Carefully remove the fan from its port. You may need to use a little force as there will be an adhesive on the right side of the fan keeping it in place.
- Locate the Molex cable connecting the fan to its port in the top left corner.
- Disconnect the cable.

To reassemble your device, follow these instructions in reverse order.