



# Acer Chromebook C740-C4PE Solid State Drive Replacement

Use this guide to replace the Solid State Drive in Acer Chromebook C740-C4PE

Written By: Sang Huynh



This document was generated on 2019-10-23 05:15:47 PM (MST).


## INTRODUCTION

This guide will show you how to change the Solid State Drive in Acer Chromebook C740-C4PE.

### TOOLS:

- **Phillips #0 Screwdriver** (1)
- **Spudger** (1)

## Step 1 — Solid State Drive



**i** Make sure the laptop is turned off and laid down on a flat surface.

- Unscrew the 13 screws on the back of the device using a PH0 Phillips head screwdriver.
- Use the spudger or any other prying tool to pry the back plate off of the device.


**!** Be sure not to pry too hard as it may result in snapping the back plate.

## Step 2



- Remove the 3.75 mm screw with a Phillips #0 screwdriver.

## Step 3



- Pull the Solid State Drive out of the connector.

To reassemble your device, follow these instructions in reverse order.