



Acer Iconia One 8 Rear Camera Replacement

This will show a step by step guide of how to replace the rear camera in your Acer Iconia One 8 B1-850 tablet.

Written By: Josh Cooper



INTRODUCTION

This will show a step by step guide of how to replace the rear camera in your Acer Iconia One 8 B1-850 tablet.

TOOLS:

- [iFixit Opening Tools](#) (1)
- [Spudger](#) (1)
- [Precision Tweezers Set](#) (1)

Step 1 — Rear Camera




- The first step to replacing the rear camera on your Acer tablet is to remove the Back Panel. To do that, use your iFixit opening tool to pry open the device in the small crevice. Do this gently in order not to crack the screen on your tablet.

Step 2



- To remove the ZIF connector on the rear camera, gently use the flat end of your spudger to lift it up and free the rear camera.

Step 3



- In order to gently remove the camera, grab the precision tweezers and carefully pull out the connector to remove the camera.

To reassemble your device, follow these instructions in reverse order.