



Acer Iconia Tab A501 Back Cover Replacement

Back cover replacement guide for the Acer Iconia Tab A501.

Written By: Trey Bazinet



INTRODUCTION

The back cover keeps the device components separate from the outside world. If it is damaged, you may decide to replace it. This guide will show you how to replace the back cover of the Acer Iconia Tab A501.

TOOLS:

- [iFixit Opening Tools \(1\)](#)

Step 1 — Back Cover



 Turn off your device before opening it.

- Use a plastic opening tool to carefully separate the back cover, starting at the volume buttons.
- Continue separating the back cover along the short side closest to the camera and around the device.

Step 2



- When separated enough, a little more than halfway around the device, the back cover will be easy to take off.

To reassemble your device, follow these instructions in reverse order.