




# Acer Iconia Tab B1 Factory Hard Reset/Password Removal

Written By: ZFix



## INTRODUCTION

If it says "Too many pattern attempts..." or not working Android system, or you want to erase all data.

**Video tutorial:**\_\_\_\_\_


[video: <http://www.youtube.com/watch?v=WioXs4vTG10>]

## Step 1 — Acer Iconia Tab B1 Factory Hard Reset/Password Removal



- From the reset hole we can make reset without erasing data.

## Step 2




- Power off the tablet. Push and hold **Vol(+)** and **Power On** keys together in the same time.

## Step 3




- Now you are in the Boot Mode menu. With **Vol(+), (-)** go to **[SD Update Image Mode]** and select it with **Power On key**.
- Pressing the Power On key too quickly may turn off the tablet screen. You'll need to press and hold for about a second to select **[SD Update Image Mode]**.

## Step 4



- Now you are in **Android System Recovery Menu**. Choose "wipe data / factory reset", "Yes -- delete all user data". And finally "reboot system now".

## Step 5



- After restart you will have empty (free of data) device and access to it.

To reassemble your device, follow these instructions in reverse order.