



Acer Iconia W3-810 Back Panel Replacement

How to take the back panel off of the Acer Iconia W3-810.

Written By: Griffin Hocker



INTRODUCTION

This is a short and simple guide showing how to properly remove the back panel. Following these steps will prevent you from breaking anything. These steps are also included in all other guides, as they are the necessary first steps for each guide.

TOOLS:

- [iFixit Opening Tools \(1\)](#)

Step 1 — Back Panel



- Place the tablet face down on a flat surface with the charger facing toward you.

Step 2



- Use a plastic opening tool to pry the back panel off of the device.

⚠ Be careful to not use the plastic opening tool near the charging dock or any media ports.