



Acer One 10 S1003-19GY Back Panel Replacement

Use this guide to replace the back panel of your Acer One 10 S1003-19GY.

Written By: Trey Wintzinger



INTRODUCTION

This guide will show how to remove the back panel from the device to access interior components.

TOOLS:

- [iFixit Opening Tools](#) (1)

Step 1 — Back Panel



- Power off the device and make sure it is disconnected from any external devices.
- Use a plastic opening tool to create a gap between the front and back casing of the device.
- Slowly maneuver the plastic tool around the entire perimeter of the tablet to separate the front and back.

Step 2



- Set the device screen side down and remove the back casing.

