




Acer Spin 3 SP315-51-757C Back Panel Replacement

How to remove the back panel of the Acer Spin 3 SP315-51-757C.

Written By: Skyler Ognibene




INTRODUCTION

In order to replace any parts inside the Acer Spin 3 SP315-51-757C, you will have to remove the back panel first. This guide can be completed very quickly and easily, as you will only need to remove some screws with a Phillips #0 screwdriver and pull the panel off the laptop using a plastic opening tool.

TOOLS:


- [Phillips #0 Screwdriver \(1\)](#)
- [iFixit Opening Tools \(1\)](#)
- [iFixit Opening Picks set of 6 \(1\)](#)

Step 1 — Back Panel



- Remove eleven Phillips #0 screws from the back panel.

Step 2



- Using an opening tool, pry open the back panel, starting at the silver screen hinges.
- (i)* You may need to apply more force than usual. If you don't find any success at the hinges, you can try to start at another area that looks easier to open.
- (i)* You can also use some plastic opening picks to help hold parts of the panel open while you work on other sides.

Step 3



- Lift the back panel off of the laptop.

To reassemble your device, follow these instructions in reverse order.