




# Acer TravelMate TMB115-M-C99B Battery Replacement

How to replace the Acer TravelMate TMB115-M-C99B battery.

Written By: Audrey Williams



---

## INTRODUCTION

If your laptop is not responding or showing any sign of powering on, use this guide to remove and replace your battery.



### TOOLS:

- [Phillips #0 Screwdriver](#) (1)
  - [iFixit Opening Tools](#) (1)
  - [Magnetic Project Mat](#) (1)
-


## Step 1 — Battery



 Turn off your laptop before starting.

- Flip the laptop over so the model stickers face the ceiling.

## Step 2



- Remove the thirteen 6mm Phillips screws using the #0 screwdriver.
- Remove the back of the laptop.





## Step 3



- Remove the two 7mm Phillips screws from the battery using the #0 screwdriver.

## Step 4



- Unplug the battery from the motherboard.

To reassemble your device, follow these instructions in reverse order.