



Acer TravelMate TMB115-M-C99B Hard Drive Replacement

How to replace the Acer TravelMate TMB115-M-C99B hard drive.

Written By: Tanvi Kharkar



INTRODUCTION

If your laptop is not properly storing or recovering files, use this guide to remove and replace your hard drive.

TOOLS:

- Phillips #0 Screwdriver (1)
- iFixit Opening Tools (1)
- Magnetic Project Mat (1)


Step 1 — Battery

 Turn off your laptop before starting.

- Flip the laptop over so the model stickers face the ceiling.



Step 2



- Remove the thirteen 6mm Phillips screws using the #0 screwdriver.
- Remove the back of the laptop.

Step 3



- Remove the two 7mm Phillips screws from the battery using the #0 screwdriver.

Step 4



- Unplug the battery from the motherboard.

Step 5 — Hard Drive



- Carefully disconnect the hard drive from the motherboard.

To reassemble your device, follow these instructions in reverse order.