



# Alcatel IdealXCITE Battery Replacement

How to replace the battery in an Alcatel IdealXCITE.

Written By: Franklin Froehlich



## INTRODUCTION

If you need to replace the battery in your Alcatel IdealXCITE because it won't hold a charge or turn on, you should use the following guide. The Alcatel IdealXCITE contains a lithium ion battery which can short out and catch fire, proceed with caution and do not puncture the battery.



## PARTS:

- [Replacement Battery \(1\)](#)

[Battery](#)

## Step 1 — Battery



- Place your finger in the small notch on the left corner of the phone.
- Use your finger to gently pull up on the back cover where the notch is located.
- Gently pull up on the back cover, working around the phone.
- Remove the cover from the phone, and set it aside for later installation.

## Step 2



- Place your thumb in the small notch between the battery and the phone.
- Use your thumb to gently pry the battery up at the notch, releasing it from the phone.

 Take note of the contacts in the phone and on the battery for reinstallation.

In order to reassemble your device, follow the instructions in reverse order.