



# Alesis Palmtrack V3.1 Teardown

Opening and disassembling of the Alesis Palmtrack V3.1

Written By: Lorca Strand



 **TOOLS:**

- [Phillips #00 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)

## Step 1 — Alesis Palmtrack V3.1 Teardown



- Open the back battery cover

## Step 2




- Unscrew the four back screws

## Step 3




- Remove the backing and the wire mesh microphone casing.
- NOTE: The Speaker is connected to the motherboard and adhered to the back cover, so take caution when opening. I cannot foretell the chaos created if you break the speaker wire.

## Step 4



- Gently pull apart main plate from front cover.
- Also note that there is a ribbon cable connecting the front circuit board to the motherboard

## Step 5



- Disconnect the ribbon cable.

## Step 6



- Feed the ribbon cable through this opening. This is much easier than disconnecting from the front circuit board, which requires delicate, if not impossible maneuvers to reconnect upon reassembly.