



# Alldaymall A88X Back Cover

PREREQUISITE

Written By: Drhaber



# INTRODUCTION

## PREREQUISITE

### **TOOLS:**

- [iFixit Opening Tools](#) (1)

## Step 1 — Alldaymall A88X Back Cover



- Using a plastic opening tool, carefully pry the device apart. Make your way around the entire perimeter of the device and carefully place the two panels next to each other.
- ⚠ After the panels are separated, watch out for the speaker on the rear panel as its wire is rather short.
- ⓘ When separating the panels keep an eye out for the power button and volume rocker as they can be dislodged.

## Step 2



- Grip the speaker from the sides with your fingers or a pair of tweezers and slowly begin to remove it from the rear panel.
- ⚠ When removing the speaker, make sure not to disconnect the wires in any way.
- After the speaker has been removed, place the rear panel aside.

To reassemble your device, follow these instructions in reverse order.