



# AlphaSmart Pro Batteries Replacement

This guide will instruct you on how to easily remove the batteries from the AlphaSmart Pro.

Written By: Ashley Orr



## AlphaSmart® Pro INSTRUCTIONS

### To begin

- Turn on the AlphaSmart and start typing.
- Your text will appear in the window. You can use the arrow keys to move around and the Delete key to erase. AlphaSmart supports eight separate files. To go to file 1, press the F1 key. Press F2 to go to file 2, and so on up to F8 for file 8.

### To change the transfer speed to your Macintosh® or IBM-compatible PC

- Press Alt-Option-S to access the speed menu.
- Choose the desired speed from the menu (for detailed information see manual).

### To transfer text to your Macintosh® or IBM-compatible PC

- Turn on the Macintosh or PC.
- Start up your word processing application and open a new file.
- Macintosh: Unplug the cable from the Macintosh keyboard and plug it into the AlphaSmart.
- PC: Unplug your keyboard from the PC. Using a PC-to-AlphaSmart cable, plug one end into the PC keyboard port and the other end into the AlphaSmart.
- Press the Send key on the AlphaSmart.
- Your text will appear on the Macintosh or PC screen.
- To open a new file (for example, File 2) when connected to the computer, Press Alt-Option-F2 for a Macintosh, or Press Option-F2 for a PC.
- Unplug the cable from the AlphaSmart and reattach the keyboard to the Macintosh or PC.

### To finish up

- At the Macintosh or PC save the new file.
- At the AlphaSmart, press the Clear File key and follow the directions on the screen.

### Turn off the AlphaSmart when you're finished using it.

### To order:

Intelligent Peripheral Devices, Inc.  
30360 Town Center Lane, Suite 270  
Cupertino, CA 95014  
1 (408) 252-9400

<http://www.alphasmart.com>

AA 0596-5956

### Model ALF-C01, Serial number:

\*See owners manual for detailed use information.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.  
FCC ID: X2VALPHASMArt001

Made in U.S.A.

PATENT Nos: 5,410,005 & 5,085,360

## INTRODUCTION

This guide teaches you how to remove the battery cover and batteries.

## Step 1 — Removing The Battery Cover.



**⚠** Before attempting to remove batteries, make sure the device is turned off.

- Locate the battery compartment on the back of the AlphaSmart Pro.
- Push the tab inward and lift up. This will detach the cover from the device.

## Step 2 — Removing The Batteries



- Remove each battery by using your fingers or the spudger to pry them from the compartment.

To reassemble your device, follow these instructions in reverse order.