



Written By: Piper Kaul



INTRODUCTION

In this guide, you will follow the easy steps to replace dead batteries in your Fire TV Cube Remote. This task should only take a few minutes and require little force.

TOOLS:

- [iFixit Opening Tools](#) (1)
-



Step 1 — Remote Battery



- On the back of the remote, press down on the indentation to slide the cover.
- Lift up on the back cover and remove the back.

Step 2



- Remove batteries.
-  You may use either hands or a plastic opening tool for this step.
-  Be sure you match the positive and negative ends with their receivers.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-11-05 06:00:27 PM (MST).

