



Anker Vertical Mouse Teardown

This guide will show you the innards of this mouse if you need to repair or replace a component.

Written By: Emily Harris



Step 1 — Unscrew the bottom board



- Insert wisdom here.

Step 2 — Unscrew the top cover



- Insert wisdom here.

Step 3 — Remove the Mouse Wheel



- Insert wisdom here.

Step 4 — Connect the right click button to the Scroll Wheel



- Insert wisdom here.

Step 5 — Remove the two halves of the mouse



- Insert wisdom here.

Step 6 — Remove the button covers



- Insert wisdom here.

To reassemble your device, follow these instructions in reverse order.