



Anki Vector Belts Replacement

This guide will show users how to remove and replace the Anki Vector's movement belts.

Written By: Shay Takei



INTRODUCTION

Should your Anki Vector go over any rough terrain or just accumulate wear over time, you will need to replace its belts.

This guide will help you if the Anki Vector's wheel belts have become visibly damaged or too stiff to allow proper movement.

You will not need any special equipment for this guide.

Step 1 — Belts



- Raise Vector's arms above his head.

Step 2



- Using your thumb and index finger, grab the lower portion of the belt near the large wheel and pull the belt off.
- Repeat on the other side.

To reassemble your device, follow these instructions in reverse order.