



# Apple iPod Hi-Fi Batteries Replacement

How to remove and replace the batteries of the Apple iPod Hi-Fi.

Written By: Timothy Scheuermann



## INTRODUCTION

This guide details how to replace the batteries in the Apple iPod Hi-Fi speaker system.

### TOOLS:

- [Coin](#) (1)
- [Spudger](#) (1)

## Step 1 — Batteries



- Put your coin in the battery lock on the back of the the Hi-Fi. Turn the coin to the left to release the battery panel.
- Remove the battery panel with your hands.

**i** You can also use a metal spudger or flathead screwdriver to open the battery lock instead of a coin.

## Step 2



- Remove the six D batteries from the device.

To reassemble your device, follow these instructions in reverse order.