



Asus A53U-ES21 Battery Replacement

In this guide, we will remove and replace the battery in your Asus A53U-ES21.

Written By: Chase Poirier



INTRODUCTION

The Asus A53U-ES21 comes with a 6-cell Li-Ion battery. Over time, the capability of the battery can deteriorate and power your laptop for less and less time. This guide will explain how to replace your battery with a new Li-Ion battery, which can dramatically increase the life of your device.

Step 1 — Battery



 Make sure the laptop is off.

- Flip the laptop upside down so that the battery is facing you.

Step 2



- Move the two sliders towards the outer edge of the laptop.
- Pull the battery out with your left hand while holding the right slider.

To reinsert the battery, follow these instructions in reverse order.