



Asus F554LA-WS52 Keyboard Replacement

How to replace a Asus F554LA-WS52 keyboard.

Written By: Aaron Ratliff




INTRODUCTION

If you have updated your keyboard drivers and the keyboard is still unresponsive, you can use this guide to replace it. You will need a Phillips #0 screwdriver and a plastic opening tool.

TOOLS:

- [Phillips #0 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)


Step 1 — Keyboard



⚠ Make sure the notebook is off and has been unplugged from any power source.

- Flip the notebook over and remove the 10 screws from the back plate with a #0 Phillips head screwdriver.
- *(i)* Six (6) will be 9.6mm and four (4) will be 12.7mm.

Step 2



- Flip the notebook back over.
- Gently lift and remove the keyboard with a plastic opening tool.

Step 3



- (Not pictured) Remove the three cables attached to the keyboard and one from the touch-pad.
- (Not pictured) With the plastic opening tool, pry off the metal separation plate from the keyboard.
- (Not pictured) With the plastic opening tool, gently pry the keyboard from its position and replace.

To reassemble your device, follow these instructions in reverse order.