




Asus G73JH-RBBX05 Keyboard Replacement

Replace the keyboard on the Asus G73JH-RBBX05

Written By: Josh DeBest



INTRODUCTION

Use this guide to remove the keyboard on the Asus G73JH-RBBX05.



TOOLS:

- Metal Spudger (1)
- Spudger (1)

PARTS:


- ASUS ROG G73Jh Keyboard (1)

Step 1 — Keyboard



- Locate the 5 clips located at the top of the keyboard. Insert a metal spudger into the clip openings on the keyboard to remove the keyboard.

Step 2



- Before fully removing the keyboard, remove the back lighting cable and keyboard data strip.
- In order to remove these cables, push forward the black retention clips and pull out the cables.

To reassemble your device, follow these instructions in reverse order.