



Asus G73JW-XT1 Battery Replacement

Can't seem to charge your battery? It may be time to replace it. This guide will walk you through the simple steps to replace your Asus laptop battery.

Written By: Emma Plass



INTRODUCTION

Use this guide to replace the battery of an Asus G73JW-XT1 laptop.

Ensure that laptop is unplugged from any power source before you begin the replacement.

Step 1 — Battery



- Flip the device over so the battery port is easy to access.

Step 2



- Slide the left slider to the left so that it locks in place.
- Slide the right slider to the right while pushing the battery away from you. The battery should disconnect.

To reassemble your device, follow these instructions in reverse order.