



Asus N56VM Hard Disk Replacement

Written By: Stanky





TOOLS:

- [Mako Driver Kit - 64 Precision Bits](#) (1)
-

Step 1 — Remove battery




- Remove the battery and the AC power

Step 2 — Remove bottom cover




- Remove the M2x4 screw of the bottom cover
- Remove the bottom cover by sliding it downwards

Step 3 — Hard Disk



- Remove the screws
 - Remove the 3 M2x10 screws
 - Remove the one M2x4 screw

Step 4



- Gently pull the hard disk to the left

To reassemble your device, follow these instructions in reverse order.