



# Asus Q200E-CT144H Battery Replacement

How to remove and replace the battery for the Asus Q200E-CT144H laptop.

Written By: Kirsti Wattles



## INTRODUCTION

If you've noticed that your laptop is not turning on, or maybe there is a problem with charging your Asus Q200E-CT144H laptop, use this guide to replace your battery/connector. The purpose of the battery/connector is to provide electricity in order to power on the laptop. If the battery goes to waste, then there is no way to operate the laptop, therefore making it useless as a whole. The Lithium-ion battery is an important component of the typical laptop.

### TOOLS:


- [iFixit Opening Tools](#) (1)
- [Phillips #00 Screwdriver](#) (1)
- [Tweezers](#) (1)

## Step 1 — Back Cover




- To start, turn off the laptop and disconnect the power cable.
- ⚠ If the computer is on or plugged in, it could cause electric shock.
- Flip the laptop over so the back panel is visible.

## Step 2




- Remove the 9 screws holding the cover in place by taking a Phillips #00 Screwdriver and turning it counterclockwise.

## Step 3




- Use an iFixit opening tool to lift the back cover and remove it from the laptop.

## Step 4 — Battery



- Remove the battery connector by using tweezers to lift up on it.


## Step 5



- Remove the nine Phillips #00 screws that hold the battery in place.

*(i)* There is one 9.2mm screw, four 4.7mm screws, and four 5.7mm screws.

## Step 6



- Remove the battery from the battery bay.

To reassemble your device, follow these instructions in reverse order.